

MINI-MAX, BRS SOFTPACK INSTALLATION

1. Make slots in rear spar carry-thru to facilitate pack straps. Locate holes to coincide with top of lower frame member of carry-thru. See detail "A"
2. Install cross member in this location to provide a secure attachment to the lower pack straps. See detail "B".
3. Extremely Important. Make sure Rocket and Parachute has a clear trajectory. Shoulder straps must be secured well out of the way.

