

MINI-MAX, BRS HARNESS ROUTING

1. S-fold and tie-wrap Main Bridle in position between Links on bag. Attach loops to Quick-Links.
2. Route left Harness section over top of turtledeck. Secure Kevlar Harness sections in place by applying 1.8oz. fabric over them.
3. Route right Harness section as shown. Harness may have to have excess taken up by S-folding and securing with tie-wraps. Make sure none of the Harness assembly is routed over top of Rocket or pack opening.

IMPORTANT: Make sure Harness assemblies are routed over TOP of shoulder straps. Serious injury could result if system is deployed with BRS Harnesses routed under your shoulder harness.

